

Remember to clean all halogen bulbs with isopropyl alcohol before installing. Any contaminate can cause the bulbs to overheat and they will burn out quickly.

For five watt, WM halogen cluster bulbs, it is HIGHLY recommended that 4 to 6, 1/8"-3/16" holes be drilled in the cluster housing above the lamp locations. The 3 watt bulbs run hot, the 5 watt run even hotter. Ventilation will help minimize deformation of the housing. See the photo below for positions of the vent holes.



Thanks,
The Wagonmeister

